



Hall Technologies • 1234 Lakeshore Dr Suite #150 Coppell, TX 75019 • halltechav.com

HT-ASTRO2-4

4-Port USB 2.0 Extender, 50m

USER MANUAL

May 25, 2023



Important Safety Instructions



1. Do not expose this apparatus to rain, moisture, dripping or splashing and that no objects filled with liquids, such as vases, shall be placed on the apparatus.



2. Do not install or place this unit in a bookcase, built-in cabinet or in another confined space. Ensure the unit is well ventilated.



3. To prevent risk of electric shock or fire hazard due to overheating, do not obstruct the unit's ventilation openings with newspapers, tablecloths, curtains, and similar items.



4. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.



5. Do not place sources of naked flames, such as lighted candles, on the unit.



6. Clean this apparatus only with dry cloth.



8. Protect the power cord from being walked on or pinched particularly at plugs.



9. Only use attachments / accessories specified by the manufacturer.



10. Refer all servicing to qualified service personnel.

Table of Contents

Introduction	4
Overview	4
Features.....	4
Package Contents	5
Connectors & Indicators.....	6
HT-ASTRO2-4-TX.....	6
HT-ASTRO2-4-RX.....	7
Applications.....	8
Setup	9
Installation.....	9
Troubleshooting	10
Specifications	11

Introduction

OVERVIEW

The HT-ASTRO2-4 is a 4-port plug-and-play USB2.0 extender via a single Cat5e/Cat6 cable. This extender hub kit transmits data from a PC to as many as four USB 2.0 peripherals up to 50m/165ft. The transmitter is powered by the USB port from the PC and the 4-port receiver is powered locally to provide access to keyboard, mouse, printers, scanners, cameras, speakers, external storage media, digital signage or automated control systems.

The HT-ASTRO2-4 works with all major operating systems including Windows, MacOS and Linux with no need of driver installation and is also compatible with USB 1.1 and USB 3.0 peripherals.

FEATURES

- Supports high-speed USB2.0 (up to 480Mbps) over Cat5e/Cat6 cables up to 50m/165ft.
- 4x USB peripherals connected to the receiver and supports an additional receiver to be connected to increase USB peripherals up to 7 (when fully loaded the max transmission distance will decrease to 40m/130ft).
- TX powered by the USB port, RX powered by lockable DC supply with 500mA to each USB device (receiver hub does not need power adapter when only keyboard and mouse is used)
- True plug-and-play with no driver installation required.
- Supports all major operating systems – Windows, MacOS and Linux
- Compatible with USB1.1 and USB3.0 peripherals.
- Hub receiver supports additional USB hub connection and up to 7 x USB peripherals connected. (When fully loaded, the max transmission distance may be shortened to 40m.)


Package Contents

HT-ASTRO2-4

- 1x Transmitter Unit
- 1x Receiver Unit
- 1x Power Adapter (DC 18V 0.5A)
- 4x Mounting Brackets (with screws)

Connectors & Indicators

HT-ASTRO2-4-TX



No.	Name	Description
1	STATUS	<ul style="list-style-type: none">• On: The device is working properly.• Off: The device is not working properly.
2	POWER	<ul style="list-style-type: none">• On: The device is powered on.• Off: The device is powered off.
3	USB HOST	USB 2.0 Type-B for connection to host PC.
4	UTP OUT	RJ45 connector for Cat5e cable connected to the receiver.

HT-ASTRO2-4-RX




No.	Name	Description
1	DC 12V	DC 12V/0.5A power supply connection for local power. Note: adapter is not needed if only connecting one keyboard and one mouse.
2	POWER	<ul style="list-style-type: none"> On: The device is powered on. Off: The device is powered off.
3	STATUS	<ul style="list-style-type: none"> On: The device is working properly. Off: The device is not working properly.
4	UTP IN	RJ45 connector for Cat5e cable connected to the transmitter.
5	USB	USB 2.0 Type-A for peripheral devices.

Applications

A laptop or PC is connected to the USB Type-B interface on the HT-ASTRO2-4-TX and then transmitted over the category cable to the HT-ASTRO2-4-RX, where multiple USB peripheral devices are connected.

Commented [BG1]: Need to add the applications image. 1 application would be for 1 to 1 TX/RX. The other application would be for cascading mode, adding up to 8 receivers.



Setup

INSTALLATION

Note: Before installation, please ensure the devices are disconnected from the power source.

To install the device on a surface:

1. Secure the included L-bracket mounts to each side of the transmitter/receiver using the included screws.



2. The bottom part of the L-bracket will slightly raise the transmitter/receiver and will create a small gap between the device and the mounting surface.
3. Using the appropriate hardware (not included), mount the bottom of the L-brackets to the desired surface.

Commented [BG2]: We will need better pictures - these are just for place holders.

Troubleshooting

Problem Type	Problem	Options
Control	Mouse or other peripheral not seen at laptop	Confirm the connectors are properly seated on each device
		Test the category cable to confirm proper pinout and no shorts in the cable
		Confirm the distance between the transmitter and receiver does not exceed specifications (depending on the USB bandwidth)

Specifications

Technical	
Input	1 x USB Type-B
Output	4 x USB Type-A
Input/Output Signal Type	USB 2.0 up to 480Mbps
Transmission Distance	USB 2.0: 50m (165ft) max, Cat5e UTP

General	
Operating Temperature	0°C to 45°C (32°F to 113°F)
Storage Temperature	-20°C to 70°C (-4°F to 140°F)
Humidity	10% to 90%, non-condensing
Power Consumption	4.5W max
Power	1x DC 12V/0.5A (included)
Dimensions	55mm W x 16mm H x 45mm D (2.17" W x 0.63" H x 1.77" D)
Weight	80g (0.176 lbs.)



© Copyright 2022. Hall Technologies
All rights reserved.

1234 Lakeshore Drive, Coppell, TX 75019
halltechav.com / support@halltechav.com
(714)641-6607