



HR-4P

Projector Controller Programmable I/O Serial Device



HR-4P Programmer Software Version 2.0 Help File

CUSTOMER SUPPORT INFORMATION

Order toll-free in the U.S. 800-959-6439
FREE technical support, Call 714-641-6607 or fax 714-641-6698
Mail order: **Hall Research**, 1163 Warner Ave. Tustin, CA 92780
Web site: www.hallresearch.com E-mail: info@hallresearch.com

Table of Contents

OVERVIEW	2
GETTING STARTED.....	2
SOFTWARE GUI INSTALLATION	2
USING THE SOFTWARE.....	3
BUTTON SELECTION	3
CONNECT/DISCONNECT	3
CONFIGURATION	6
I/O CONTROL.....	10
IR.....	11
COMMUNICATIONS.....	13
MENU SYSTEM	13
FILE.....	13
TOOLS.....	13
HELP.....	14
RS232 COMMAND SUMMARY	14
TROUBLESHOOTING	15
PRG VS RUN MODE DEMYSTIFIED	15

Overview

The HR-4P Programmer is a Windows™ Software GUI used to:

- Configure the function of individual I/O lines as input or output
- Build Action Strings (actions are triggered by state changes on the input lines)
- Upload and download configuration strings
- Learn or playback Infra-Red Remote Control codes
- Download, Upload, Edit and Save configuration information

Getting Started

The HR-4P Programmer is recommended to run on a compatible PC with Windows™ XP or later operating system.

Note *Microsoft™ .NET Framework 2.0 or later is required prior to installing the HR-4P Programmer. Most new PCs come with Microsoft™ .NET Framework 2.0 or later already installed. If .NET Framework 2.0 or later is not installed on your PC, it can be found on the Microsoft™ website.*

Software GUI Installation

- If the software has been previously installed, you must UNINSTALL the program from the Add/Remove Programs selection of the control panel.
- The software is installed by running the SETUP.EXE program on the installation source.
- The typical user should be able accept all the default settings.

Once the HR-4P Programmer Software installation has completed, a desktop icon will appear as well as on the start menu under:



Start->Programs->Hall Research->HR-4P Programmer

Using the Software

- Double click the desktop icon or its program menu selection and the main screen will be displayed as shown below in Figure1.




Figure 1 – Main

Button Selection

The main screen has four buttons along the left side shown in Figure 1, These are the most commonly used functions.

Connect/Disconnect

In order for the software to communicate with the HR-4P unit, it must be connected to serial port on the computer.

Note *Most PCs and notebooks do not have a serial port. So to program the HR-4P you may need a USB to RS-232 Serial converter. These are available from Hall Research P/N USB-RS232-1*



Model HR-4P Programmer

Connect the HR-4P to the RS-232 port using a F/F Cross-Over DB9 cable (included in the package). For the unit to use its RS-232 in programming and/or command input mode, you need to slide the switch next to the serial connector to PRG mode. The LED over the switch will start blinking.



- Click the **Communications** tab to verify or change the COM port selection. This setting will be remembered for future use. The baud-rate in PRG mode (for use with GUI) is fixed.
- To open a serial connection to the unit, click the **Connect** button on the left side of the screen to attempt a connection to the HR-4P. The button will automatically change and say **Disconnect**. There are also **Connect** and **Disconnect** buttons on the **Communications** tab that perform the same functions.
 - If a connection was established between the software and the unit, the GUI main screen will update as shown in Figure 2. Note that the bottom lower left of the screen will always show the current connection status.
- To close the serial connection, click the **Disconnect** button on the left side of the screen, or click the **Disconnect** button in the **Communications** tab.




Figure 2 – Main

Download

- Click the **Download** button on the left of the Main screen to retrieve the current configuration strings stored in a HR-4P unit and into the GUI software.
- As the configuration screens are downloaded, the GUI interface will update with the retrieved settings.



Note You will see smaller Download button icons peppered throughout the pages of the GUI. The big download button along the left column downloads EVERYTHING from the target unit. If you just want to download a specific command or configuration, then you use the small download buttons. The buttons have tooltips, so if you hover your mouse pointer over them, you will see a pop-up text that explains exactly what it will do.

Show Config

- Click the **Show Config** button to display the current configuration present in the GUI. Figure 3 below shows an example of a unit's configuration. All INPUT Strings and IR Codes are available
- Configuration settings can be saved and loaded from disk by using the "FILE" menu at the top of the main screen.
- Configuration settings can be uploaded into the HR-4P unit by clicking the **Upload** button displayed on the left of the main screen.
- Configuration settings can be downloaded in the GUI by clicking the **Download** button displayed on the left of the main screen.




Figure 3 – Sample Configuration Display

Model HR-4P Programmer

Upload

- Click the **Upload** button on the left of the Main screen to store the current configuration strings in a HR-4P unit from the GUI software. All information stored in the HR-4P will be overwritten.



Note You will see smaller Upload button icons peppered throughout the pages of the GUI. The big Upload button along the left column Uploads EVERYTHING to the target unit. If you just want to Upload a specific command or configuration, then you use the small Upload buttons. The buttons have tooltips, so if you hover your mouse pointer over them, you will see a pop-up text that explains exactly what it will do.

Main Screen Tabs

The HR-4P Programmer consists of four different pages in a tabular format. Each Tab has a specific function

Configuration

The **Configuration** tab page as seen in Figure 4 is the default tab shown at software startup. This tab allows the user to build configuration strings (also known as Action Strings). A configuration string can be created to perform one or more specific actions based on a particular condition.





Figure 4 – Configuration Tab

Programmable Serial Controller

A configuration string can be up to 250 bytes long, and it can be any combination of: *serial, time delays, IR codes, outputs, and pulses actions*. The action strings you are building use bytes for identifying the desired action. For example, a Serial Commands uses XX+2 bytes where XX is the number of bytes the user defines. For example “Hello” uses 4 bytes + 2 bytes for the serial command. You are limited to 250 bytes for any particular action string.

Condition – Here you are specifying what real-world event to look for on the I/O ports configured as input (or the CTS line pin 8 which is always an input), you can also specify the direction of a change as high-to-LOW, or low-to-HIGH. So, for example you can issue a command when a contact closes and a different command when a contact opens. If you just want to issue a single command (when your input is a momentary switch), all you have to do is define the action for either Low, or High going pulse. If defined for High, then when the external momentary switch opens, the action is triggered.



Action

This is what you want to do when the above condition is detected. Action strings can be complex and have any combination of the following (the only limitation is the maximum bytes your defined action can have):

Serial is used to send specific serial characters to a device (such as turning a Projector ON or OFF)

IR is used to send an IR code to an IR enabled device

Delay is used to add a time delay

Output is used to toggle a specific output on and off

Pulse is used to send timed on/off/on or off/on/off to a output

Serial Commands

- A serial command can send data to any standard serial device with selectable baud rate and parity. When sending serial commands, you can also specify a delay between characters to meet varying requirements.
- Serial commands can be mixed with other actions for the same input. For example, you may have a projector configuration string like “PWR_ON” followed by a **DELAY** followed by an **OUTPUT**. There is no limit to the number of actions that can be added as long as the 250 character limit is observed.
- Hexadecimal characters may be entered by using **&H** in front of the 2 digit Hexadecimal character.
- Select the desired **Condition** and change **Action** to **Serial**. Commands are entered in the **Command** text box. When done, the user clicks the **Add** button to append the command as shown in Figure 5.




Figure 5 – Serial Commands

IR Codes

IR code's can be part of the configuration string. Supported IR formats are available for sending known IR Addresses and Commands. Ensure that the IR Protocol, Address and Commands have been tested to ensure proper response from the controlled devices. A compatible IR Emitter is required to send IR Codes.



CIR-EMT
[IR Emitter Cable](#)

- Select the desired **Condition** and change **Action** to **IR**. When done, the user clicks the **Add** button to append the command as shown in Figure 6.

A screenshot of a software interface for configuring IR codes. It features a 'Condition' dropdown set to 'CTS High' and an 'Action' dropdown set to 'IR'. A blue instruction bar reads: '* To build a string, Select Desired Condition & Action. When done, press the Add button.' Below this, the 'IR Protocol' is set to 'Extended NEC'. There are three input fields: 'Hi Address (Hex): DB', 'Lo Address (Hex): 24', and 'IR Command (Hex): 1C'. An 'Add' button is to the right of these fields. A text box at the bottom shows the resulting string: 'IR - 6,DB,24,1C'. A 'Clear' button is to the right of the text box. At the bottom right, there are two small icons: a yellow folder and a green leaf.

Figure 6 – IR Code

- If you know the IR Protocol and the command for the device you want to control, then all you have to do is to select the protocol (like RC5, NEC, JVC, etc) from the dropdown list and enter the address and command (for example Hall Research uses NEC protocol for most of its Scaler products and we publish the IR codes!).
- If you don't know the IR protocol or command for your device, or if the protocol is not supported, you can "Learn" the desired IR codes and program them into the HR-4P. The "Learning" process is described later and required an IR Detector/Receiver cable



CIR-DET-D2
[IR Receiver Cable \(Type 2\)](#)

Programmable Serial Controller

- Up to 32 IR Codes that have been 'learned' can be transmitted from the unit.
- Select the desired **Condition**, change **Action** to **IR**, change **IR Protocol** to **Memory Recall** and select the desired **location** that the IR code was saved into.
- When done, click the **Add** button to append the command as shown in Figure 7.

The screenshot shows a software interface for configuring an IR Memory Recall command. At the top, there are two dropdown menus: 'Condition' set to 'CTS High' and 'Action' set to 'IR'. Below these is a blue instruction bar that reads: '* To build a string, Select Desired Condition & Action. When done, press the Add button.' Underneath, there is another dropdown menu for 'IR Protocol' set to 'Memory Recall', followed by a text input field for 'Name' containing the word 'Power'. To the right of the 'IR Protocol' dropdown is a blue 'Add' button. Below the 'Name' field, there is a dropdown menu for 'Location' set to '1'. At the bottom of the configuration area, there is a text area containing the string 'IR - 9,01,00'. To the right of this text area is a 'Clear' button and two small icons (a yellow one and a green one).

Figure 7 – IR Memory Recall

Time Delay

- Time delay's can be added to configuration strings as needed. Delay's can from milliseconds to 255 minutes. Multiple delays can be entered if longer times are required.
- When done, click the **Add** button to append the command as shown in Figure 8.

The screenshot shows a software interface for configuring a Time Delay command. At the top, there are two dropdown menus: 'Condition' set to 'CTS High' and 'Action' set to 'Delay'. Below these is a blue instruction bar that reads: '* To build a string, Select Desired Condition & Action. When done, press the Add button.' Underneath, there is a 'Time Delay' section with three spinners: the first is set to '0' (min), the second to '15' (sec), and the third to '0' (ms). To the right of these spinners is a blue 'Add' button. Below the spinners, there is a text area containing the string 'Delay - 00:15:00'. To the right of this text area is a 'Clear' button and two small icons (a yellow one and a green one).

Figure 8 – Time Delay

Output

- If any of the units I/O is configured as an output, you can control that output based on a specific input condition.
- Select the **Output** from the **Action** drop-down menu and pick a desired output **channel** state, either ON or OFF.
- When done, the user clicks the **Add** button to append the command as shown in Figure 9.

Model HR-4P Programmer

Condition: CTS High Action: Output

* To build a string, Select Desired Condition & Action. When done, press the Add button.

Channel: Output 3 Off Add

Output - Output 3 Off Clear

Figure 9 – Output

Pulse

- If any of the units I/O is configured as an output, you can pulse that output one or more times based on a specific input condition. The Pulse Width and Delay between Pulses is selectable in milliseconds. The delay is only required when more than one pulse is being sent.
- Select the **Pulse** from the **Action** drop-down menu and pick a desired output **channel**, the **Number of Pulses** and the **Pulse Width**.
- When done, the user clicks the **Add** button to append the command as shown in Figure 10.

Condition: CTS High Action: Pulse

* To build a string, Select Desired Condition & Action. When done, press the Add button.

Channel: Output 4 Pulse Width (ms): 1 Add

Number of Pulses: 1

Pulse - Output 4,1,1,1 Clear

Figure 10 – Pulse

I/O Control

- The **I/O Control** tab allows the user to configure any or all four discrete I/O's as inputs or outputs.
- An input can be defined as **Input-Contact** or **Input-Voltage**. When an input is defined as “contact” you can just use a contact closure or switch to ground with no additional circuitry, or use a digital signal that swings anywhere from 0 to 24v. In this mode the input of HR-4P is high impedance (>50 KOhm). When an input is defined as “voltage” then the HR-4P will terminate the input with a 1K ohm resistor to ground. In this mode it will not be able to sense a contact to ground (since the pull-down resistor is already keeping the pin at ground potential), but it is useful for sensing DC supplies that can be a DC voltage from 3 to 24 vDC.

A good example is if you want to detect 110 VAC. In that case you can simply use a small 6v DC power adapter and plug it into the AC line, and tie the 6v DC to the HR-4P. When configured as Voltage input, the 1K resistor will bleed off and decay the DC signal from the external supply when the AC voltage is disconnected.

Programmable Serial Controller

- Any I/O configured as inputs may have the current status read by clicking the **I/O Status** button.
- Any I/O configured as outputs may have the output state set by selecting the appropriate control button.

I/O Status

1 2 3 4

- RTS is an OUTPUT, CTS is an INPUT. Action based configuration strings can be created for the CTS Input only.
- The HR-4P unit is assigned a common address value of 01 by factory default, and it is just part of the unit's info for your convenience and serves no other purpose (you can tag your units with a number between 1 and 255 for future reference).
- After using the **Connect** button and establishing communication with a HR-4P unit, this tab will show the units **Firmware Version** Number as well as its programmed **Address**.





Figure 11 – I/O Control

IR

- The **IR** tab is used to configure the IR capabilities of the HR-4P unit. A compatible IR Detector and Emitter are required to fully utilize the IR features.
- When the IR is configured as an **Input**, the HR-4P unit can learn any supported IR codes from the user's remote control. These IR codes can be stored into 1 of 32 IR Memory locations in the unit.
- IR codes stored in memory can have an 8 character name associated with it, making it easier to be identified later.
 - Check the **IR Enabled** box
 - To **LEARN** IR Codes
 - Select the **Input** radio button and click **Upload**
 - Install IR Detector on HR-4P Unit
 - Click the **LEARN** button
 - Press IR Remote Control button while pointing at IR Detector
 - Store code learned into IR Memory Location with name if desired
 - To **SEND** IR Codes



Model HR-4P Programmer

- Select the **Output** radio button and click **Upload**
- Install IR Emitter
- Recall IR memory location (or test IR code by entering IR address & command)
- Click the **SEND** button to play the remote code from the HR-4P unit

Note

Storing and Recalling IR codes from memory locations are ONLY allowed when the HR-4P unit is in the program mode.




Figure 12 – IR Learn




Figure 13 – IR Send

The learned IR codes can be played back from the GUI as described above in PRG mode, or after programming is done and the Mode Switch is in RUN position, input high/lo conditions can be used to trigger I/O commands.

A typical use for HR-4P would be to use it to issue Learned IR commands based on RS-232 input. Then you need to keep the unit in PRG mode all the time and communicate with it at 19,200 baud and issue the following command:

IRS9,Location<cr> where location is 1 through 32 (that of memorized location)

Communications

- The **Communications** tab page can be used to select a COM port of your PC to talk to the HR-4P unit. Once, the preferred COM port is selected, pressing the **Connect** button either in this tab page or on the left of the Main screen to make a serial connection.
- Since GUI communicates with the HR-4P's serial port at a fix baud rate of 19200, no parity, 1 stop bit, and 8 data bits, those selections are fixed. The COM port is the only selection that needs to be set as shown in Figure 14.




Figure 14 – Communications

Menu System

The HR-4P Programmer consists of three menus which allow you to easily perform more specific tasks.

File

The **File** menu consists of the following menu items as shown in Figure 15.

- **New** – Clear all user configuration strings and IR codes currently stored in the HR-4P Programmer.
- **Open** – Open a text file to load user configuration strings, I/O configuration, and IR codes into the HR-4P Programmer.
- **Save** – Save user configuration strings, I/O configuration, and IR codes from the HR-4P Programmer into a text file.
- **Exit** – Exit the HR-4P Programmer.



Figure 15 – File Menu

Tools

The **Tools** menu consists of the following menu items as shown in Figure 16.

- **Reset Unit** – Reset your HR-4P unit after a new I/O configuration or IR configuration.
- **Factory Defaults** – Clear all user configuration strings and IR code stored in HR-4P unit, re-initialize I/O and IR configurations.
- **Refresh** – Refresh the tab page.




Figure 16 – File Menu

Help

The **Help** menu consists of the following menu items as shown in Figure 17.

- **Contents** – Display the help file contents. A PDF reader will be required in order to view the document.
- **About...** – Display the Version and Support information for the software.




Figure 17 – Help Menu

RS232 Command Summary

The HR-4P uses a simple command protocol that can be used by other software in order to control and/or configure the unit.

- The unit uses a baud rate of 19200, 8 Data bits, 1 Stop bit and No Parity and it must be in **PRG MODE** (Power Led is blinking)
- The HR-4P supports a command format as shown in the following table.
 - `<cr><lf>` in the table below denote the CARRIAGE RETURN (0x0D) and LINEFEED (0x0A) Characters
 - Each command is terminated by a single CARRIAGE RETURN `<cr>`

Command	Function	Response
VER? <code><cr></code>	Read Firmware version	Version x.y <code><cr><lf></code> where X.Y is the firmware version
CLnm <code><cr></code>	Configure I/O line n to m <input type="checkbox"/> n = 1 to 4 <input type="checkbox"/> m = 1 : 2 : 3 : ? = contact input : voltage input : output : status	Nothing except Status Reads return: CLX1 = I/O line X configured as contact type input <code><cr><lf></code> CLX2 = I/O line X configured as voltage type input <code><cr><lf></code> CLX3 = I/O line X configured as output <code><cr><lf></code>
IOnm <code><cr></code>	Set or Read State of I/O line n to m <input type="checkbox"/> n = 1 to 4 = output <input type="checkbox"/> m = 0 : 1 : ? = low : high : status	Input X = 1 or 0 <code><cr><lf></code> Output X = 1 or 0 <code><cr><lf></code>
TOGn <code><cr></code>	Toggle the state of I/O line n <input type="checkbox"/> n = 1 to 4	Input X = 1 or 0 <code><cr><lf></code> Output X = 1 or 0 <code><cr><lf></code>
IRCN <code><cr></code>	Set or inquire IR <input type="checkbox"/> n = 0 : 1 : ? = input : output : status	IRC0 = IR configured as Rxd <code><cr><lf></code> IRC1 = IR configured as Txd <code><cr><lf></code>
IRSn,m <code><cr></code>	Send IR code stored in 1 of 32 IR memory locations <input type="checkbox"/> n = 9 (Learned IR) <input type="checkbox"/> m = 1 – 32 (Memory Location)	Nothing
IRSn,m,k <code><cr></code>	Send IR code with a specified IR protocol, IR address, and IR command <input type="checkbox"/> n = 0 - 6 (NEC, JVC, Sharp, RCA, RC5, Sony-sirc, and Extended NEC) <input type="checkbox"/> m = 0 - 255 (or 0 - 65535 for Extended NEC) = IR address in DECIMAL <input type="checkbox"/> k = 0 - 255 = IR command in DECIMAL	Nothing
IRPn <code><cr></code>	Set or Read Current IR protocol State <input type="checkbox"/> n = 0 - 5 (NEC, JVC, Sharp, RCA, RC5, and Sony-sirc) <input type="checkbox"/> n = ? = status	IRP0 = Current IR protocol = NEC <code><cr><lf></code> IRP1 = Current IR protocol = JVC <code><cr><lf></code> IRP2 = ... and so on
RTSn <code><cr></code>	Set or Read State of RTS line <input type="checkbox"/> n = 0 : 1 : T : ? = low : high : toggle : status	Nothing except Status Reads return: RTS? = RTS0 <code><cr><lf></code> or RTS1 <code><cr><lf></code>
CTSn <code><cr></code>	Read State of CTS line <input type="checkbox"/> n = ? = status	CTS? = CTS0 <code><cr><lf></code> or CTS1 <code><cr><lf></code>
FDFT <code><cr></code>	Factory default	Are you sure (Y,N)? User must send CAPITOL "Y" before 8 Second Timeout
RST <code><cr></code>	Unit Reset/Restart	
MODE <code><cr></code>	Return current mode status <input type="checkbox"/> 00 = Run mode <input type="checkbox"/> 01 = Program mode	00 or 01 <code><cr><lf></code>
RE <code><cr></code> or re <code><cr></code>	Reserved – Active only in PROGRAM MODE	Factory use only
WE <code><cr></code> or we <code><cr></code>	Reserved – Active only in PROGRAM MODE	Factory use only
RDIO <code><cr></code>	Reserved – Active only in PROGRAM MODE	Factory use Only
RDIN <code><cr></code>	Reserved – Active only in PROGRAM MODE	Factory use Only

Troubleshooting

If you are having trouble configuring or communicating with the HR-4P unit, check:

UNIT SEEMS DEAD	Comments
Check that the unit is powered with the supplied power supply and operating normally.	With SWITCH in RUN Position the LED should be on SOLID With SWITCH in PRG Position the LED should be BLINKING
GUI WON'T RUN	
Verify that program installs without errors	
Verify that the .NET Framework 2.0 minimum has been installed	
COMMUNICATIONS PROBLEMS WITH GUI	
Set switch to PRG position when using the GUI	The LED should be BLINKING
Ensure RS232 cable used is compatible with the PC being used	This is normally a NULL-MODEM cable with pins 2 & 3 crossed. Only Pins 2, 3 and 5 are used for serial communication
Ensure PC COM port is set correctly on the COMMUNICATIONS TAB	
UNIT DOESN'T CONTROL SERIAL DEVICE	
Verify unit and Serial Device have proper serial interconnect cabling	Straight Cable or Null-Modem
Verify via PC and Hyperterminal that unit outputs proper characters at proper baud rate when the appropriate event occurs.	
Verify serial device can be controlled via HyperTerminal or similar program	
Set switch to RUN position when unit is put into service	The LED should be on solid

PRG vs RUN mode Demystified

In **Run** mode the unit does not pay attention to any RS-232 data coming from external device. Hence, the RS-232 port is used only to send out data (as defined in Action Strings). This is done because the unit has its own command set that it understands (described in last section), and if it were paying attention to the incoming data, upon getting wrong commands it will output "Err".

So if, for example, if you have connected the serial port to a projector and your defined Actions are sending commands to the projector, the returned data from the projector need to be ignored, lest they be interpreted as commands!

In **PRG** mode the unit pays attention to incoming RS-232 data. However, if Actions are triggered by input state changes, all aspects of the Actions are executed except serial output part. This is done because if you were connected to the PC and running the GUI, and if inadvertently you trigger an Action String with serial output, that data it would crash the GUI!

In PRG mode the unit does, however, execute other portions of your defined Action such as blasting IR outputs, or changing I/O output state (high, low, or pulse).